



Twin Tec *Installation Instructions for Twin-Cam Coil P/N 2009*

CAUTION: CAREFULLY READ INSTRUCTIONS BEFORE PROCEEDING

OVERVIEW

The Twin Tec P/N 2009 coil is intended for 2001-2006 Harley-Davidson® Twin-Cam 88® applications with Delphi fuel injection. The P/N 2009 coil will fit in place of stock P/N 31743-01 and has a four terminal primary connector. It cannot be used on 2001 fuel injected engines with the Magneti-Marelli® system.

INSTALLATION

1. Turn off the ignition switch and disconnect the battery ground cable before proceeding.
2. Remove the coil cover. Note the orientation and routing of the spark plug wires. Disconnect and remove the stock coil.
3. Apply silicone dielectric grease to the high voltage coil terminals to reduce corrosion and prevent arcing. Make sure that the plug wires have tight fitting boots and the proper size terminals. If your motorcycle is still equipped with the original carbon core suppression plug wires, this is a good time to consider a high quality spiral core wire set such as the Twin Tec P/N 3002 universal set.
4. Install the new P/N 2009 coil and reconnect the battery ground cable.



WARNING: To avoid ignition system damage from coil arcing, never crank the engine while any spark plug wire is disconnected. Do not touch or connect any test equipment, including a timing light, to the coil while the engine is running.